
UNENCLOSED 90°/ADJACENT EXIT PLATFORM (NO PIT) VPL-3100/VPL-3200B SERIES VERTICAL PLATFORM LIFT



NOTES: 1) ACCESS RAMP CAN BE MOUNTED ON EITHER SIDE OF THE PLATFORM ILS-00934 ALL DIMENSIONS CHANGED TO FRACTIONS 2) SEE ILS-00938 FOR LANDING GATE DETAIL/ALIGNMENT

SHEET 1 OF 4 REV. 4 (4770)(5-10-11)(DRS)

Bruno Independent Living Aids, Inc., 1780 Executive Drive, P.O. Box 84, Oconomowoc, WI 53066 Phone (800) 882-8183 Fax (262) 953-5501


Any reproduction or other use of these materials without written permission of Bruno Independent Living Aids, Inc. is expressly prohibited. Bruno independent Living Aids, Inc. reserves the right to modify or make changes to these specifications at any time with out notice.



UNENCLOSED 90°/ADJACENT EXIT PLATFORM (NO PIT)

VPL-3100/VPL-3200B SERIES VERTICAL PLATFORM LIFT ANCHOR POINT LOCATIONS/SLAB DETAIL

	Н	J	K
48" PLATFORM	7 5/8"	12 1/16"	66"
54" PLATFORM	10 5/8"	15 1/16"	72"
60" PLATFORM	13 5/8"	18 1/16"	78"



UNITS WITH 90°/ADJACENT EXIT PLATFORM

TECHNICAL SPECIFICATIONS


FLOOR ATTACHMENT:

VPL MUST BE FASTENED TO CONCRETE SLAB USING FOUR (4) 1/2" (3/8" BOLT) X MINIMUM 2-1/2" LONG CONCRETE ANCHORS SUITABLE FOR THE ENVIRONMENT. FOLLOW SELECTED CONCRETE ANCHOR MANUFACTURERS GUIDELINES AND APPLICABLE CODES.

FLOOR REQUIREMENTS:

4" THICK 3500 PSI MINIMUM COMPRESSIVE STRENGTH, REINFORCED CONCRETE SLAB.


For complete technical specification please see ILS-00834 "VPL-3100 Series Residential Vertical Platform Lift Technical Specification" ILS-00986 "VPL-3200B Series Residential Vertical Platform Lift Technical Specifications"





UNENCLOSED 90°/ADJACENT EXIT PLATFORM (NO PIT)

VPL-3100VPL-3200B SERIES VERTICAL PLATFORM LIFT



NOTES: 1) ACCESS RAMP & PLATFORM GATE CAN BE MOUNTED ON EITHER SIDE OF THE PLATFORM
SIDE OF THE PLATFORM
2) SEE ILS-00938 FOR LANDING GATE DETAIL/ALIGNMENT

Bruno Independent Living Aids, Inc., 1780 Executive Drive, P.O. Box 84, Oconomowoc, WI 53066 Phone (800) 882-8183 Fax (262) 953-5501


Any reproduction or other use of these materials without written permission of Bruno Independent Living Aids, Inc. is expressly prohibited. Bruno Independent Living Aids, Inc. reserves the right to modify or make changes to these specifications at any time with out notice.



UNENCLOSED 90°/ADJACENT EXIT PLATFORM (NO PIT) VPL-3100/VPL-3200B SERIES VERTICAL PLATFORM LIFT

ANCHOR POINT LOCATIONS/SLAB DETAIL

	Н	J	K
48" PLATFORM	7 5/8"	12 1/16"	67 1/2"
54" PLATFORM	10 5/8"	15 1/16"	73 1/2"
60" PLATFORM	13 5/8"	18 1/16"	79 1/2"



UNITS WITH 90°/ADJACENT EXIT PLATFORM WITH PLATFORM GATE

TECHNICAL SPECIFICATIONS

FLOOR ATTACHMENT:

VPL MUST BE FASTENED TO CONCRETE SLAB USING FOUR (4) 1/2" (3/8" BOLT) X MINIMUM 2-1/2" LONG CONCRETE ANCHORS SUITABLE FOR THE ENVIRONMENT. FOLLOW SELECTED CONCRETE ANCHOR MANUFACTURERS GUIDELINES AND APPLICABLE CODES.

FLOOR REQUIREMENTS:

4" THICK 3500 PSI MINIMUM COMPRESSIVE STRENGTH, REINFORCED CONCRETE SLAB.

For complete technical specification please see ILS-00834 "VPL-3100 Series Residential Vertical Platform Lift Technical Specification" ILS-00986 "VPL-3200B Series Residential Vertical Platform Lift Technical Specification"

